

PRIMERGY BX620 S4 サーバブレード ご使用上の注意

このたびは、弊社の製品をお買い上げいただきまして、誠にありがとうございます。本製品をご使用になる上での注意事項がござりますので、本書をよくお読みの上ご使用願います。

2008年2月
富士通株式会社

1 マネジメントブレードのファームウェアについて

PRIMERGY BX620 S4 サーバブレードを、PRIMERGY BX600 S2 シャーシに搭載する場合、マネジメントブレード・ファームウェアのアップデートが必要な場合があります。サポートファームウェアの組合せ等の情報については、下記をご参照いただき、適切なファームウェアをダウンロードしアップデートをお願いします。

【PRIMERGY ホームページから参照する場合】

インターネット情報ページ (<http://primeserver.fujitsu.com/primergy/>) 内の『ブレードサーバ』 – 『ブレードサーバの留意・注意事項』

【URL 直接参照の場合】

<http://primeserver.fujitsu.com/primergy/blade/products/note.html>

注) 適切なファームウェアを適用しない場合、正常に動作しない場合があります。

以上

Notes on using PRIMERGY BX620 S4 Server Blade

Thank you for purchasing our product. Before you start using your server, please carefully read the additional notes described below.

February 2008
FUJITSU LIMITED

1. Updating of Management Blade firmware

When you install PRIMERGY BX620 S4 server blade into PRIMERGY BX600 S2 Blade Server System Unit, you may need to update firmware of management blade on it. Referring to Fujitsu PRIMERGY site at the following URL, confirm the appropriate revision of firmware, and if necessary, download and update the firmware.

<http://www.fujitsu.com/global/services/computing/server/ia/>

Note) BX620 S4 server blade may not work correctly with older revision of management blade firmware.