

PRIMERGY BX600 LAN パススルーブレード 使用上の注意

このたびは、弊社の PRIMERGY BX600 LAN パススルーブレード(以降、本製品)をお買い求めいただきまして、誠にありがとうございます。本製品をご使用になる上での注意および追記・訂正事項がございますので、本書をよくお読みの上、ご使用願います。

平成 18 年 10 月
富士通株式会社

1. 「LAN パススルーブレード(PG-LNB101)取扱説明書:B7FY-1641-01」についての訂正事項

訂正

本文中の以下の型番を読み替えてください。

- 誤) PG-LNB101
- 正) PG-LNB102

2. LAN インタフェースを使用した Teaming 機能の制限について

本製品を BX600/BX660 サーバブレードのオンボード LAN に接続して使用する場合、BX600/BX660 サーバブレードのオンボード LAN を含む Teaming 構成では、BACS/BASP、Intel®PROSet、Linux Channel Bonding 等を使用しての Teaming 機能は使用できません。この Teaming 構成で運用した場合、故障発生時に LAN の LINK ダウンを適切に検出できず、LAN ポートの切替りが動作しないか、切替りに時間がかかる場合があります。

なお、Teaming を使用せずに、LAN ポート単独での LAN 接続は可能です。

また、BX620 S2 サーバブレードのオンボード LAN、および、LAN ドータカード／LAN 拡張ボードのみでチームを構成する場合は Teaming 機能をご使用になれます。以下の表は本製品に接続する LAN インタフェースと単独 LAN 接続、Teaming 機能のサポート対応表です。

LAN パススルーブレード接続対象	単独 LAN 接続	Teaming 機能
BX600 サーバブレード オンボード LAN	○	未サポート
BX660 サーバブレード オンボード LAN	○	未サポート
BX620 S2 サーバブレード オンボード LAN	○	○
BX620 S3 サーバブレード オンボード LAN	○	○
LAN ドータカード(PG-LND101)／ LAN 拡張ボード(PG-LND102)	○	○

以上

Notes on using the GbE Pass-Thru Blade

Thank you for purchasing the GbE Pass-Thru Blade from us. Before you start using the product, please carefully read the additional notes described below.

October, 2006
Fujitsu Limited

1. Correction to the GbE Pass-Thru Blade User's Guide : B7FY-1641-01

Correction

Product ID reference is corrected in the document as follows:

False: PG-LNB101
True: PG-LNB102

(End)