

内蔵LT0ユニットPG-LT101/PGBLT101をバックアップキャビネットPRIMERGY S10に搭載する場合の制限事項

このたびは、弊社の内蔵LT0ユニットPG-LT101/PGBLT101をお買い求めいただきまして、誠にありがとうございます。本製品をバックアップキャビネットPRIMERGY（プライマジー）S10に搭載してご使用になる上での制限事項がございますので、本書をよくお読みの上ご使用願います。

平成14年1月
富士通株式会社

制限事項

内蔵LT0ユニットPG-LT101/PGBLT101をバックアップキャビネットPRIMERGY（プライマジー）S10に搭載した場合、PRIMERGY S10の電源ONはサーバ本体の電源ONと連動しますが、電源OFFはサーバ本体の電源OFFと連動しません。

PRIMERGY S10とサーバ本体の電源OFFを連動する必要がある場合は、無停電電源装置（UPS）を併用してPRIMERGY S10の電源を制御してください。

またUPSを使用しないでPRIMERGY S10の電源を切断する場合は、いったんACケーブルを抜いてください。

Restriction When Using the Tape Drive LTO with PRIMERGY S10

Thank you for purchasing the Fujitsu Tape Drive LTO PG-LT101/PGBLT101.

Pay attention to the following restriction when using this product with PRIMERGY S10.

Restriction

When Tape Drive LTO PG-LT101/PGBLT101 is installed in PRIMERGY S10:

Although PRIMERGY S10 is switched on with the server's power on, it is not switched off when a system shutdown is performed. If you need to switch off PRIMERGY S10 with server's power off, please use UPS. PRIMERGY S10 can be switched off by disconnecting the power cable when PG-LT101/PGBLT101 is installed.