

PRIMERGY ServerView 使用上の 留意事項について

このたびは、弊社の PRIMERGY をお買い求めいただきまして、誠にありがとうございます。
本製品『PRIMERGY ServerView』をご使用になる上での留意事項がございますので、本書をよくお読みの上ご使用ねがいます。

重要

2001年2月
富士通株式会社

本使用上の注意事項はサーバ本体添付品とともに、大切に保管してください。

1. AC 切断・投入についてのご注意

本サーバにおいて、AC 切断・投入（UPS によるスケジュール運転を含む）によるシステム起動で Popup メッセージの表示および NT イベントログ（エラー）が格納されますが、システム動作には影響ありません。

Popup メッセージ

Alarm received from server N400

An error was recorded on server N400. See server management event / error log (Recovery) for detailed information.

以下に、UPS によるスケジュール運転が正常に動作している場合の NT イベントログの情報例をしめします。

なお UPS ベンダにより NT イベントログ情報が若干違いがありますのでご注意ください。

(1) PowerChute plus (APC 社製)での NT イベントログは以下のように格納されます。

NT イベントログ(システム)

日付	時刻	ソース	種類	分類	イベント ID	ユーザ	コンピュータ	説明
2001/2/1	18:42:34	Server Control	エラー	なし	10634	N/A	N400	An error was recorded on server N400. See server management event / error log (Recovery) for detailed information.
2001/2/1	18:41:06	UPS	情報	なし	1002	N/A	N400	UPS との通信が確立しました。
2001/2/1	18:41:58	UPS	情報	なし	1001	N/A	N400	*** PowerChute plus バージョン 5.2.0.3J 起動***
AC OFF での電源切断状態								
2001/2/1	18:41:58	UPS	情報	なし	1001	N/A	N400	*** PowerChute plus バージョン 5.2.0.3J 停止***
2001/2/1	18:42:34	Server Control	エラー	なし	10621	N/A	N400	The reason <Software command> N400 causes a shutdown at server N400

(2) NetPowerView F (富士電機社製)での NT イベントログは以下のように格納されます。

NT イベントログ(システム)

日付	時刻	ソース	種類	分類	イベント ID	ユーザ	コンピュータ	説明
2001/2/1	18:42:34	Server Control	エラー	なし	10634	N/A	N400	An error was recorded on server N400. See server management event / error log (Recovery) for detailed information.
2001/2/1	18:41:06	UPSMAN	情報	なし	7	N/A	N400	Service has started.
AC OFF での電源切断状態								
2001/2/1	18:42:34	Server Control	エラー	なし	10621	N/A	N400	The reason <Software command> N400 causes a shutdown at server N400

2. ServerView の「電源」表示および、「環境」表示のご注意について

下記接続条件の場合、「PRIMERGY S30 (ハードディスクバート) : PG-R1DC6」の情報は正しく表示されません。

- PG142B/C (PCI カード) 1 枚に「PRIMERGY S30 (ハードディスクバート) : PG-R1DC6」を 2 台接続。

Notes when using the PRIMERGY ServerView

Thank you for purchasing the PRIMERGY series server.

Before operating the "ServerView" software for the PRIMERGY server, make sure to thoroughly read and understand the following notes.

Important

Feb/2001 FUJITSU Ltd.

Carefully store this document along with the supplied server parts in safekeeping.

1. Notes when the AC power off/on

After switching off and on the AC power of the server, sometimes the following error message will pop up, and the following event will be logged into the NT Event Viewer.

However, this will not give any influence to the system behavior, so please ignore them.

Example) Popup message

Alarm received from server xxxx

An error was recorded on server xxxx. See server management event / error log (Recovery) for detailed information.

xxxx : Computer name

Example) Event Log (APC PowerChute plus)

Date	Time	Source	Type	Category	Event	User	Computer	Description
2001/2/1	18:42:34	Server Control	Error	None	10634	N/A	xxx	An error was recorded on server N400. See server management event / error log (Recovery) for detailed information.
2001/2/1	18:41:58	UPS	Information	None	1001	N/A	xxx	*** PowerChute plus Version 5.2.0.3J Started***
The server is power-off status. (AC power is off)								
2001/2/1	18:41:58	UPS	Information	None	1001	N/A	xxx	*** PowerChute plus Version 5.2.0.3J Stopped***
2001/2/1	18:42:34	Server Control	Error	None	10621	N/A	xxx	The reason <Software command> N400 causes a shutdown at server N400

Example) Event Log (Fujitsu NetPowerView F)

Date	Time	Source	Type	Category	Event	User	Computer	Description
2001/2/1	18:42:34	Server Control	Error	None	10634	N/A	xxx	An error was recorded on server N400. See server management event / error log (Recovery) for detailed information.
2001/2/1	18:41:06	UPSM AN	Information	None	7	N/A	xxx	Service has started.
The server is power-off status. (AC power is off)								
2001/2/1	18:42:34	Server Control	Error	None	10621	N/A	xxx	The reason <Software command> N400 causes a shutdown at server N400

2. Notes for the 'Power Supply' and 'Environment' window. (Known Bug)

Under the following condition, ServerView cannot show the proper information about the PRIMERGY S30(PG-R1DC6, Storage Subsystem).

Condition : Two S30-cabinets are connected to one PG142B or PG142C simultaneously.