

PRIMERGY ServerView V0 3.02

L10 をご使用のお客さまへ

このたびは、弊社の PRIMERGY をお買い求めいただきまして、誠にありがとうございます。本書は本体添付の「PRIMERGY ServerView V03.02 L10」の使用上の注意事項です。本説明書をよくお読みになり正しくお使いいただきますよう、お願いいたします。

重要

2002年1月
富士通株式会社

PRIMERGY ServerView V03.02 L10(SV03.02 と称します)は、サーバの監視処理を行うために必要です。本使用上の注意事項はサーバ本体添付品とともに、大切に保管してください。

はじめに

PRIMERGY ServerView V0 3.02 L10 は、弊社 PRIMERGY 専用のサーバ監視ツールです。

Microsoft, Windows, Windows NT は米国 Microsoft Corporation の米国およびその他の国における登録商標です。その他の製品名等は各開発メーカーの商標です。

All Rights Reserved, Copyright(C) FUJITSU LIMITED 2002

1. ハードウェア要件

- ・ PRIMERGY の以下の対象モデルでのみ動作します。
PRIMERGY B125

サポート OS は以下の通りです。

- ・ Microsoft Windows NT ® Server Network Operating System Version 4.0 SP 6a 以降
- ・ Microsoft Windows NT ® Server Enterprise Edition Version 4.0 SP 6a 以降
- ・ Microsoft Windows ® 2000 Server Operating System SP1 以降
- ・ Microsoft Windows ® 2000 Advanced Server Operating System SP1 以降

また、以下の OS が動作するクライアントパーソナルコンピュータ上で使用になれます。

- ・ Microsoft Windows NT ® Workstation Network Operating System Version 4.0 SP 6a 以降
- ・ Microsoft Windows ® 2000 Professional Operating System SP1 以降

2. 本 CD-ROM の使い方

本 SV 03.0 2 のセットアップについては、本体装置に添付されております「PRIMERGY ソフトウェアガイド」に従って処理を行ってください。

また、ServerWizard を使用して本 SV 03.0 2 を自動的にインストールすることが出来ます。

- 注意： - PRIMERGY B125 に ServerWizard を使用して ServerView を自動インストールする場合
- ・ ServerWizard を使用して Windows NT 4.0 をインストールする場合、ServerWizard の事前設定で「Service Pack を適用する」のチェックを行い、ServerWizard CD-ROM に同梱されている Service Pack を適用してください。
 - ・ Service Pack を適用しない場合、ServerWizard を使用して ServerView を自動インストールすることはできません。この場合、Windows NT4.0 をインストール後に手動でディスプレイドライバを適用し、手動で ServerView をインストールする必要があります。

3. SV 03.0 2 の取扱いについて

本 CD-ROM の下記フォルダ内に「ServerView ユーザーズガイド」(取扱説明書)がオンラインマニュアルとして格納されています。

ServerView : < C D ドライブ > ¥SVMANAGE¥JAPANESE¥MANUAL¥SV_V0302.PDF

オンラインマニュアルは PDF 形式の為、Acrobat Reader を使用します。

本体装置に添付されております ServerWizard CD-ROM 内に格納されている、Acrobat Reader のインストールを行なうことで参照できます。

- ・ CD-ROM ドライブに ServerWizard CD-ROM をセットして下さい。
- ・ ServerWizard Launcher 画面が表示されます。「EXIT」をクリックして終了させてください。
- ・ ServerWizard Launcher の終了処理において、画面上に「CD-ROM のロックを解除します」のポップアップメッセージが表示されます。
- ・ 「CD-ROM のロックを解除します」のポップアップメッセージが消えたあと、エクスプローラ等を使用して、下記フォルダより、Acrobat Reader のインストールを行って下さい。

ServerWizard : < C D ドライブ > ¥DRIVERS¥UTILS¥Acrobat¥Ar500jpn.exe

4. 注意事項

SV 03.0 2 使用に関する注意事項

- ・ SV 03.0 2 に関する注意事項は、インストール後に「Fujitsu ServerView Hints」が作成されます。「Fujitsu ServerView Hints」内には、ご使用にあたっての重要な情報が記載されておりますので、必ずご一読されますようお願いいたします。

OS 起動後、スタートメニューから ” プログラム ” ” Fujitsu ServerView ” ” Fujitsu ServerView Hints ” と選択してください。

- 以上 -

PRIMERGY ServerView V03.02

L10 User Notes

Fujitsu would like to thank you for purchasing a PRIMERGY series server.

This document provides explanatory notes when using the “PRIMERGY ServerView V03.02 L10” tool, included with the server.

Please read this document and understand its contents thoroughly before commencing operation.

IMPORTANT

Jan/2002
FUJITSU Ltd.

PRIMERGY ServerView V03.02 L10 (referred to as SV03.02) is required to properly monitor the server. Carefully store this document along with the supplied server parts in safekeeping.

PREFACE

PRIMERGY ServerView V03.02 L10 is an exclusive server-monitoring tool for the PRIMERGY series of servers.

Microsoft, Windows and Windows NT are registered trademarks of Microsoft Corporation in the United States and other countries. Other product names are the registered trademarks of their respective makers.

All Rights Reserved, Copyright © FUJITSU LIMITED 2002

1. Hardware Environment

? This tool applicable to the following PRIMERGY model **PRIMERGY B125**

Supporting OSes are as follows:

- ? Microsoft Windows NT ® Server Network Operating System Version 4.0 SP 6a, or later
- ? Microsoft Windows NT ® Server Enterprise Edition Version 4.0 SP 6a ,or later
- ? Microsoft Windows ® 2000 Server Operating System SP1, or later
- ? Microsoft Windows ® 2000 Advanced Server Operating System SP1, or later

The following OSes can be used on the client PC:

- ? Microsoft Windows NT ® Workstation Network Operating System Version 4.0 SP 6a, or later
- ? Microsoft Windows ® 2000 Professional Operating System SP1, or later

2. Using the CD-ROM

SV03.02 can be setup either manually, by following the “PRIMERGY Software Guide” or automatically, by using the ServerWizard CD-ROM.

Cation:

- When installing ServerView on a PRIMERGY B125

Automatic installation of ServerView using the ServerWizard CD-ROM is not possible if the OS installed is Windows NT 4.0.

In this case manually install the display driver after the Windows NT 4.0 installation has completed, then proceed with the ServerView installation.

3. How to View SV 03.02

The CD-ROM contains an online manual version of the "ServerView User's Guide" (user's manual), which is stored in the below folder:

ServerView:<CD-ROM drive>: ¥SVMANAGE¥ENGLISH¥MANUAL¥SV_V0302.PDF

This online manual being in PDF format can viewed using Acrobat Reader.
Acrobat Reader can be installed from the ServerWizard CD-ROM provided with this server.

Insert the ServerWizard CD-ROM into the CD-ROM drive.

- ? The ServerWizard Launcher screen will appear. Click [EXIT] to close the screen.
- ? Once the ServerWizard Launcher screen has closed, a "Release the CD-ROM lock" popup message will appear.
- ? After the "Release the CD-ROM lock" popup message disappears, using Explorer etc., install Acrobat Reader from the below folder:

ServerWizard:<CD-ROM drive>: ¥DRIVERS¥UTILS¥Acrobat¥Rp500enu.exe

4. ServerView Hints

Related Operational Notes for SV 03.02

- ? After installation, SV 03.02 related operational notes are located under "Fujitsu ServerView Hints". Please make sure to read these notes as they provide important information concerning the operation of this tool.

After the OS has started up,
Select [Start] menu -> [Fujitsu ServerView] -> [Fujitsu ServerView Hints]