










Fujitsu Server PRIMERGY RX2540 M7 3.5x10




Fujitsu Server PRIMERGY RX2540 M7 3.5x12



Fujitsu Server PRIMERGY RX2540 M7 2.5x16



Fujitsu Server PRIMERGY RX2540 M7 2.5x24



Fujitsu Server PRIMERGY RX2540 M7 8×2.5+4×2.5

