
ケージナット取付け治具の使用手順について

このたびは、弊社のPRIMERGY19インチラックをお買い上げいただき、誠にありがとうございます。本製品に添付されておりますマニュアルに追記事項がありますので、本紙をよくお読みになり、正しくお使いいただきますようお願いいたします。

平成 18 年 3 月 富十通株式会社

取付け手順

1. ケージナットはラック内側より取付けます。 ケージナットの一方の爪をラックのケージナット取付け穴に引っかけます。



2. 取付け治具先端の引込み用の爪をケージナット取付け穴の手前から挿入し、 ケージナットのもう一方の爪に勘合させます。




3. ケージナットの爪と治具の爪の勘合を外さないように治具を手前に引き、 合わせてケージナットを押しつける事により、ケージナットのセットを完了します。




取外し手順

1. 取付け治具先端をケージナットの爪とラック柱の間に挿入して、ケージナットの爪を押し込みます。



2. 取付け治具をケージナットの方へ押し下げて取外します。



*ケージナットを落とさないよう注意して〈ださい。

増設,移設作業時にも本治具が必要となりますので、大切に保管してください。

以上

Using the cage nut insertion tool


Thank you for purchasing PIMRERGY 19inch Rack.

This document is for supplement of Users Guide.


Please read this supplementary document well and use it rightly.

Insertion


Install the cage nut from the inside of the mounting flange.
Insert one edge of the cage nut into the hole.



2. Insert the edge of tool from this side of a installation hole and hook the other edge of the cage nut.




3. Pull the tool and the cage nut back through the hole to complete the installation of the cage nut.




Removal

1. Insert the edge of tool into the gap of cage nut and mounting flange. Then compress the edge of the cage nut.



2. Push down the tool towards the cage nut and remove it.



*Please be careful not to drop the cage nut.

Please keep the tool. It use at the time of expansion and transference of a system.

March,2006 Fujitsu Limited