

## 本製品をPRIMEQUESTでご使用になる場合の補足事項

このたびは、弊社の内蔵 LT02 ユニット（以降「本装置」）をお買い求めいただきまして、誠にありがとうございます。本装置を PRIMEQUEST でご使用になる前に、PRIMEQUEST 本体添付 Drivers CD（以下 Drivers CD）の「LT02 TAPE Drive Users Guide (C122-E031-C2)」を、ご一読ください。なお、搭載方法については SX10 添付 CD に収められている「SX10 バックアップキャビネット取扱説明書 (B7FY-0731)」を、参照願います。本装置をご使用される前に PRIMEQUEST では以下の留意点がございますので、本書をよくお読みの上でご使用ください。

平成 18 年 9 月  
富士通株式会社

### 1. TAPE Maintenance Advisorについて

「TAPE Maintenance Advisor」は PRIMERGY 用ソフトウェアであり PRIMEQUEST では使用できません。3 ヶ月に 1 回お客様にて本装置のヘッドクリーニングを実施してください。

### 2. バックアップソフトウェアについて

下記バックアップソフトウェアは PRIMEQUEST では使用できません。

- ・ BrightStor ARCserve Backup
- ・ NetVault

### 3. ドライバインストールについて

本装置添付のフロッピーディスクのドライバは PRIMERGY 用であり、PRIMEQUEST では使用できません。ドライバは以下の Drivers CD からインストールして使用してください。

- (1) PRIMEQUEST Drivers CD for Red Hat Enterprise Linux AS v.4 (C122-E019-C2)
- (2) PRIMEQUEST Drivers CD for SUSE Linux Enterprise Server 9 (C122-E025-C2)
- (3) PRIMEQUEST Drivers CD for Microsoft Windows Server 2003 (C122-E024-C2)

インストール方法については、Drivers CD 内の「LT02 TAPE Drive Users Guide (C122-E031-C2)」を参照してください。

以上

# Notes on using internal LTO2 unit with PRIMEQUEST

Thank you for purchasing the Tape Drv LTO2 Ultrium2 200GB (simply called "this product"). Before using this product, read following guides in order to handle properly.

- "LTO2 TAPE Drive Users Guide (C122-E031-C2)" in Drivers CD-ROMs supplied with the PRIMEQUEST server (simply called "Drivers CD").
- "SX10 backup cabinet manual (B7FY-0731)" in CD-ROM supplied with the SX10.

Please read following attention carefully before using this product.

September, 2006

Fujitsu Limited.

## 1. About TAPE Maintenance Advisor

"TAPE Maintenance Advisor" is software for PRIMERGY and it is not possible to use it with PRIMEQUEST. Therefore, please perform the head cleaning of the drive once in every three months manually.

## 2. About backup software

The following backup software cannot be used with PRIMEQUEST.

- BrightStor ARCserve Backup
- NetVault

## 3. About driver installation

Floppy disk of the attachment for this product is a driver for PRIMERGY, and it is not possible to use it for PRIMEQUEST. Please install from following Drivers CD (for PRIMEQUEST) and use the driver in it.

- (1) PRIMEQUEST Drivers CD for Red Hat Enterprise Linux AS v.4 (C122-E019-C2)
- (2) PRIMEQUEST Drivers CD for SUSE Linux Enterprise Server 9 (C122-E025-C2)
- (3) PRIMEQUEST Drivers CD for Microsoft Windows Server 2003 (C122-E024-C2)

Please refer to "LTO2 TAPE Drive Users Guide (C122-E031-C2)" of Drivers CD (for PRIMEQUEST) for the installation method.