

CMA Mounting Kit in combination with RMK F1-CMA, SL (Slimline) / CMA マウントキット (RMK F1-CMA, SL (SlimLine) への取付け)

English / Deutsch / 日本語




A3C40171335

Important additional information / Wichtige zusätzliche Information / 重要な補足情報

④

CMA connector inner rail /
CMA Verbinder innere Schiene /
インナー用CMAコネクタ



The Mounting parts (4) and (5) from CMA unit (see Mounting instruction CMA 1U/2U) are already premounted on Slide-Rails of RMK F1, Slimline.

Therefore, there is no need to mount these parts during assembly CMA.
The corresponding assembly steps are to be ignored

Die Montageteile (4) und (5) der CMA Einheit (siehe Montageanleitung CMA 1U/2U) sind bereits an den Teleskopschienen des RMK F1, Slimline vormontiert.

Daher besteht keine Notwendigkeit, diese Teile bei der CMA-Montage zu verwenden.
Die entsprechenden Montageschritte sind zu übergehen.

CMAマウントキットをご使用の際に本手順を適用ください。
CMAマウントキットをご使用されない場合は本手順は不要です。

CMAマウントキットの搭載部品④と⑤は、RMK F1-CMA SL(Slimline)に既に組み込まれています。
(ケーブルマネジメントアーム (CMA-1U/2U MountingKit_CMAマウントキット) 取付け手順書 参照)

⑤

Crossbar Connector /
Querschienenverbinder /
クロスバーコネクタ



These parts can be discarded.

Die Teile können verworfen werden.

CMAの取付けに際し、搭載部品④と⑤は必要ありません。
取付け手順は省略してください。
搭載部品④と⑤は破棄できます。

Online documentation can be found on: / Online-Dokumentation finden Sie unter:
<http://manuals.ts.fujitsu.com/index.php?id=5406-5605-15408>

他社ラックへの取付け、ラックへの取付けに関する詳細は下記ページのオンラインドキュメントを参照してください。
http://jp.fujitsu.com/platform/server/primergy/manual/peri_rack.html